

Elevation Selection Chart

Note: These results are based on a standard residential sash of 0.65kg per linear metre
Non friction Interlock stays must be used
It is recommended that sash widths above 900mm use two actuators to achieve full window seal

4mm Glass

Sash Height (mm)	Sash Width (mm)				
	600	900	1200	1500	1800
300	1	1	2	2	2
400	1	1	2	2	2
500	1	1	2	2	2
600	1	1	2	2	2
700	1	1	2	2	2
800	1	1	2	2	2
900	1	1	2	2	2
1000	1	1	2	2	2
1100	1	1	2	2	2
1200	1	1	2	2	2
1300	1	1	2	2	2
1400	1	1	2	2	2
1500	1	1	2	2	

5mm Glass

Sash Height (mm)	Sash Width (mm)				
	600	900	1200	1500	1800
300	1	1	2	2	2
400	1	1	2	2	2
500	1	1	2	2	2
600	1	1	2	2	2
700	1	1	2	2	2
800	1	1	2	2	2
900	1	1	2	2	2
1000	1	1	2	2	2
1100	1	1	2	2	2
1200	1	1	2	2	
1300	1	1	2	2	
1400	1	1	2		
1500	1	1	2		


6mm Glass


Sash Height (mm)	Sash Width (mm)				
	600	900	1200	1500	1800
300	1	1	2	2	
400	1	1	2	2	2
500	1	1	2	2	2
600	1	1	2	2	2
700	1	1	2	2	2
800	1	1	2	2	2
900	1	1	2	2	2
1000	1	1	2	2	
1100	1	1	2	2	
1200	1	1	2		
1300	1	1	2		
1400	1	1	2		
1500	1	1			

8mm Glass

Sash Height (mm)	Sash Width (mm)				
	600	900	1200	1500	1800
300	1	1	2		
400	1	1	2	2	2
500	1	1	2	2	2
600	1	1	2	2	2
700	1	1	2	2	2
800	1	1	2	2	
900	1	1	2		
1000	1	1	2		
1100	1	1	2		
1200	1	1			
1300	1	1			
1400	1	1			
1500	1				

 Must use pivot brackets and restrict to 200mm maximum chain extension

 Must use pivot brackets

 Can not be used as sash is too heavy for window stay

Elevation Selection Chart

Note: These results are based on a standard residential sash of 0.65kg per linear metre
Non friction Interlock stays must be used
It is recommended that sash widths above 900mm use two actuators to achieve full window seal

10mm Glass

Sash Height (mm)	Sash Width (mm)				
	600	900	1200	1500	1800
300	1	1			
400	1	1	2	2	
500	1	1	2		
600	1	1	2	2	
700	1	1	2	2	
800	1	1	2		
900	1	1	2		
1000	1	1			
1100	1	1			
1200	1	1			
1300	1				
1400	1				
1500	1				

12mm Glass

Sash Height (mm)	Sash Width (mm)				
	600	900	1200	1500	1800
300	1	1			
400	1	1	2		
500	1	1			
600	1	1	2	2	
700	1	1	2		
800	1	1			
900	1	1			
1000	1	1			
1100	1				
1200	1				
1300	1				
1400	1				
1500	1				

16mm Glass

Sash Height (mm)	Sash Width (mm)				
	600	900	1200	1500	1800
300	1				
400	1	2			
500	1	1			
600	1	1			
700	1	1			
800	1				
900	1				
1000	1				
1100	1				
1200					
1300					
1400					
1500					

- Must use pivot brackets and restrict to 200mm maximum chain extension
- Must use pivot brackets
- Can not be used as sash is too heavy for window stay